Recessing

GENERATING HEADS & PRECISION CHAMFERING

# contents

	Automatic Recessing Tools
2	Overview of Automatic Recessing
4	Tool Selection
5	AR Series Operating Principle
7	AR Automatic Recessing Heads
12	ARSP Automatic Recessing Short Pilot Heads
15	ARX Automatic Recessing External Heads
21	ARJ Automatic Recessing Jig Type Heads
26	ARXJ Heavy Duty Jig Type Heads
29	Head Conversion and Interchangeability
32	Pilots
35	Toolholders, Cutters, and Inserts
37	Set-up and Operation
41	Application Examples
45	Nobur® JA/JC Deep Hole Automatic Recessing Heads
52	Set-up and Operation
54	Application Examples
	Generating Heads
55	Overview of Generating Heads
56	Operating Principle
58	Features and Options

- 60 Single-Slide Heads
- 62 Double-Slide Heads
- 64 Application Examples

# Precision Chamfering Tools 67 Nobur® JB Back-Chamfering Tool 68 Operating Principle 71 CNF Series Precision Chamfering Tools 72 Operating Principle 77 Nobur® JB & CNF Application Examples

82 Application Data Sheet

© COPYRIGHT 2002 COGSDILL TOOL PRODUCTS, INC. CATALOG NO. 400 7-04

# Automatic Recessing

Cogsdill offers the widest array of standard tooling and the broadest range of solutions for precision grooving, recessing, and internal and external facing and chamfering.



#### SUPERIOR CRAFTSMANSHIP

All moving parts in our recessing heads are hardened and precision ground to ensure lasting accuracy and low maintenance costs. Close tolerances virtually eliminate "backlash" during retraction, for accurate size on groove width as well as depth. All sliding surfaces have large, hardened, load-bearing areas for long life and durability. We will design and manufacture a complete tooling package for your application, including **Automatic Recessing** heads, cutters and pilots. The wide variety of standard recessing heads described in this catalog are available from stock to suit most applications and machines. Special recessing heads can be designed and manufactured for unusual applications.

#### GREATER ACCURACY, SHORTER CYCLE TIME, LOWER COST

Cogsdill Automatic Recessing Tools will save you time and money. Cycle time is reduced from minutes or hours to *seconds*. The *precision is built into the head* so that grooves and recesses can be machined with *exceptional accuracy and repeatability*. The *Automatic Recessing* head changes the operational direction by 90° (i.e., axial spindle motion is converted to radial cutter movement). Recessing operations can be performed on a variety of machines, even on a drill press.

#### SUPERIOR CONSTRUCTION

Compression of the head between the machine spindle and the workpiece or jig plate actuates a sliding inclined wedge mechanism, thereby extending the cutter. Groove depth can be machined with great accuracy.

The cutter retracts radially prior to axial withdrawal of the tool from the bore, for accurate control of groove width. This design also results in a constant linear relationship between spindle movement and cutter movement. The straight-line movement of the cutter makes cutter regrinding easier.



Cutaway view of parts machined using Cogsdill Automatic Recessing Tools. Grooves and recesses are machined with exceptional accuracy and repeatability.

# Automatic Recessing Quick Reference

TOOL SELECTION CHART

Cogsdill Automatic Recessing heads are stocked in eight basic categories, including the **AR** series and our **Nobur**<sup>®</sup> recessing heads. Head models are available to suit most applications and machining set-ups. The chart below provides a brief overview of each head type, and identifies the types of machines to which each head is suited.



# **Operating Principle**

# **AR** Series automatic recessing

The **AR** Series Automatic Recessing Tool is made up of three basic components: head, cutter, and pilot. The head is usually standard and consists of shank and tool body. All cutters and pilots are manufactured to suit your application.



# **Operating Principle**

# AR Series

Illustrated below is the basic operating principle for **AR**, **ARSP** and **ARX** Recessing Heads. The head type shown below is the **AR** model.



#### 1 Approach Stroke

The tool is rotating in a machine spindle. The spindle is lowered, and the tool moves into position.

#### 2 Feed Stroke

The pilot is located in the bore against the face of the workpiece. Downward pressure causes compression of the recessing head, thereby actuating the slide mechanism which feeds the cutter out radially into the work.

#### 3 End of Feed Stroke

The correct depth of cut is obtained when the micrometer stop bottoms against the front body, making it impossible to continue the cut. Groove location is controlled by the tool adjustment system on the shank end of the cutter.

When the spindle is retracted, pressure is relieved, and the tool is withdrawn from the bore. The cutter retracts and returns to its starting position. The piloted bearing absorbs both thrust and rotation. It remains stationary in the bore of the workpiece, under load, until the cutter is fully retracted, thereby preventing scoring of the workpiece.

#### **AR Series** AUTOMATIC RECESSING

### **AR** Recessing Head

R18

**AR**16

#### General purpose tool for use on:

- Drill presses
- Jig boring machines
- Milling machines
- CNC machines
- Tool lathes
- Turret lathes
- Horizontal boring machines
- Screw machines
- Special purpose machines

#### Features:

- Pilots off workpiece or jig plate
- Micrometer stop controls depth of cut
- Tool adjustment controls axial location
- Through-shank coolant is standard
- Overtravel shanks are standard

### AR-S Short-Length Recessing Head

A variation of the AR head is shown above. Restricted to use on CNC machining or turning centers. It does not have a micrometer stop for depth control. Depth of cut is controlled by the "Z" axis of the CNC machine; axial adjustment is controlled by tool adjustment. Through-tool coolant is standard.



# **AR** Recessing Head





The Feed Ratio is the ratio of spindle to radial cutter movement

HEAD TYPE	APPROX. CAPACITY RANGE ★	MAXIMUM CUTTER TRAVEL	SHANKS	(A) FREE LENGTH	(B) TOOL BODY	(C) Cutter Shank	(D) Master Pilot	(E) REF MIN Cutter Length	(F) BORE DEPTH	(G) OVERTRAVEL	(H) REF To front nut
	0.216		0.750in/20mm	4.083 [103.70]			ø0.591				0.157
<b>AP</b> 10	[5.5]	0.197	No 2 MT	4.894 [124.32]	ø1.58	ø0.394		1.48	0.85	0.06	
ARTO	0.984	[5.0]	SK40/CAT40	6.248 [158.70]	[ø40.0]	[ø10.0]	[ø15.0]	[37.6]	[21.60]	[1.5]	[4.0]
	[25.0]		BT40	5.657 [143.70]							
			1.000in/25mm	5.547 [140.90]			ø1.416 [ø36.0]			0.06 [1.5]	
	0.590	0.276 [7.0]	No 3 MT	5.796 [147.23]	ø2.56 [ø65.0]	ø0.630 [ø16.0]		2.03 [51.5]	1.19 [30.23]		0.187 [4.76]
AD16	[15.0]		SK40/CAT40	7.713 [195.90]							
<b>AR</b> 10	1.772		SK50/CAT50	6.299 [160.00]							
	[45.0]		BT40	7.122 [180.90]							
			BT50	8.152 [178.90]							
			30mm/1.500in/40mm	6.591 [167.40]							
	0.866 [22.0]		SK40/CAT40	8.756 [222.40]							
<b>AR</b> 20		0.394 [10.0]	SK50/CAT50	7.343 [186.50]	ø3.15 [ø80.0]	ø0.787 [ø20.0]	ø1.772 [ø45.0]	2.43 [61.8]	1.46 [37.08]	0.12 [3.0]	0.224 [5.70]
	2.362 [60.0]		BT40	8.165 [207.40]	[200.0]	[520.0]		[01.0]			
			BT50	8.087 [205.40]							

#### INCH [METRIC]

\* The capacity range shown is *not* intended as an absolute limitation. The maximum diameter shown in the chart is defined as the suggested maximum groove diameter, dependent upon cutting forces, and intended for the sake of comparison only.

# **AR** Recessing Head



1 Master Pilot	9 Coolant Pipe	20 Spring Plate Pipe	108 Oiler
2 Front Nut	10 Micrometer Nut	21 Centralising Pin	109 Retaining Screw
3 Back Plate	12 Over-rider Dowel	100 Set Screw	110 Micrometer Screw
4 Chip Guard	13 Slipper	101 Double Angular Contact Bearing	111 Disc Springs
5 Front Body	14 Slipper Pin	103 Spring	<b>112</b> Key
6 Toolslide	15 Copper Pad	104 Spring	113 Torx Screw
7 Rear Body	16 Shank	106 Tool Clamp Screw	114 Ball Bearing
8 Spring Plate	19 Back Plate Dowel	107 Tool Adjust Screw	115 Centralising Screw

# AR-S Short-Length Recessing Head



The Feed Ratio is the ratio of spindle to radial cutter movement

INCH	[METRIC]									
HEAD TYPE	APPROX. CAPACITY RANGE *	MAXIMUM CUTTER TRAVEL	SHANKS	(A) FREE LENGTH	(B) TOOL BODY	(C) Cutter Shank	(D) MASTER PILOT	(E) REF MIN Cutter length	(F) BORE DEPTH	(G) REF TO FRONT NUT
AD10 S	0.216 [5.5]	0.197	SK40/CAT40	5.705 [144.90]	ø1.58 [ø40.0]	ø0.394	ø0.591	1.48 [37.6]	0.85 [21.60]	0.157
AR 10-3	0.984 [25.0]	[5.0]	BT40	5.114 [129.90]		[ø10.0]	[ø15.0]			[4.0]
	0.590		SK40/CAT40	6.758 [171.66]					1.19 [30.23]	
	[15.0]	0.276 [7.0]	SK50/CAT50	5.345 [135.76]	ø2.56 [ø65.0]	ø0.630 [ø16.0]	ø1.416 [ø36.0]	2.03 [51.5]		0.187 [4.76]
AR 10-0	1.772		BT40	6.168 [156.66]						
	[45.0]		BT50	6.089 [154.66]						
	0.866		SK40/CAT40 7.461 [189.51]							
<b>AR</b> 20-S	[22.0]	0.394	SK50/CAT50	6.048 [153.61]	ø3.15	ø0.787	ø1.772	2.43	1.46	0.224
	2.362	[10.0]	BT40	6.870 [174.51]	[ø80.0]	[ø20.0]	[ø45.0]	[61.8]	[37.08]	[5.70]
	[60.0]		BT50	6.792 [172.51]						

\* The capacity range shown is *not* intended as an absolute limitation. The maximum diameter shown in the chart is defined as the suggested maximum groove diameter, dependent upon cutting forces, and intended for the sake of comparison only.

# **Bill of Materials**

# AR-S Short-Length Recessing Head



1 Master Pilot	8 Spring Plate	21 Centralising Pin	108 Oiler
2 Front Nut	9 Coolant Pipe	100 Set Screw	109 Retaining Screw
3 Back Plate	13 Slipper	101 Double Angular Contact Bearing	113 Torx Screw
4 Chip Guard	14 Slipper Pin	103 Spring	114 Ball Bearing
5 Front Body	16 Shank	104 Spring	115 Centralizing Screw
6 Toolslide	19 Back Plate Dowel	106 Tool Clamp Screw	
7 Rear Body	20 Spring Plate Pipe	107 Tool Adjust Screw	

#### **AR** Series Automatic recessing

### **ARSP** Short-Pilot Head



#### Features:

- For applications with work length restrictions
- Minimal overall length
- Pilots off workpiece
- Micrometer stop controls depth of cut
- Tool adjustment controls axial location
- Through-tool coolant
- Overtravel shanks are standard

### **ARSP** Short-Pilot Head





The Feed Ratio is the ratio of spindle to radial cutter movement

HEAD TYPE	APPROX. CAPACITY RANGE *	MAXIMUM CUTTER TRAVEL	SHANKS	(A) FREE LENGTH	(B) TOOL BODY	(C) Cutter Shank	(D) Master Pilot	(E) REF MIN Cutter Length	(F) BORE DEPTH	(G) OVERTRAVEL	(H) REF To front nut
	0.216		0.750in/20mm	2.510 [63.75]							
ARSP1	[5.5]	0.118	No 2 MT	3.322 [84.37]	ø1.70 [ø43.25]	ø0.394 [ø10.0]	ø0.591 [ø15.0]	1.09	0.63	0.06 [1.5]	0.160
	0.984	[3.0]	SK40/CAT40	4.675 [118.75]				[27.6]	[16.0]		[4.05]
	[25.0]		BT40	4.085 [103.75]							
			1.000in/25mm	3.699 [93.95]							
	0.590	0.590 [15.0]	No 3 MT	3.948 [100.28]	ø2.36 [ø60.0]	ø0.472	ø1.091	1.44	0.81	0.06	
ADSD2	[15.0]		SK40/CAT40	5.864 [148.95]							0.158
AKJF2	1.772	[5.0]	SK50/CAT50	4.451 [113.05]		[ø12.0]	[ø27.7]	[36.5]	[20.5]	[1.5]	[4.00]
	[45.0]		BT40	5.274 [133.95]							
			BT50	5.195 [131.95]							

\* The capacity range shown is *not* intended as an absolute limitation. The maximum diameter shown in the chart is defined as the suggested maximum groove diameter, dependent upon cutting forces, and intended for the sake of comparison only.

#### INCH [METRIC]

### **ARSP** Short-Pilot Head



1 Master Pilot **10** Micrometer Nut 19 Back Plate Dowel 107 Tool Adjust Screw 2 Front Shell 12 Over-rider Dowel 100 Set Screw **110** Micrometer Screw 3 Back Plate 13 Slipper 101 Double Angular 111 Disc Springs Contact Bearing 5 Front Body 14 Slipper Pin 104 Spring 112 Key 6 Toolslide 15 Copper Pad 105 Head Screw 7 Rear Body 16 Shank 106 Tool Clamp Screw

#### **AR Series** AUTOMATIC RECESSING

### **ARX** External Head



#### External grooving tool for use on:

- Drill presses
- Milling machines
- CNC machines
- Turret lathes
- Screw machines
- Special purpose machines

#### Features:

- Pilots off workpiece
- Micrometer stop controls depth of cut
- Tool adjustment is controlled within the fitted tooling
- Overtravel shanks are standard
- Optional balance block available with two-slot chip guard for high-speed applications



### ARX-S External Short-length head

A variation of the ARX head is shown above. Restricted to use on CNC machining or turning centers. It does not have a micrometer stop for depth control. Depth of cut is controlled by the "Z" axis of the CNC machine; axial adjustment is controlled by tool adjustment.

# **ARX** Tooling Components

#### **AR** Series Automatic recessing

**ARX** toolholder, cartridge, and insert are shown below. Replaceable carbide inserts are used where applications permit.





**ARX** toolholders, insert cartridges, and carbide inserts are made to order from standard blanks. Part pilots are designed and manufactured to suit the application; the master pilot is part of the recessing head.

# Specifications

## **ARX** External Head





The Feed Ratio is the ratio of spindle to radial cutter movement



INCU	[METDIC]
писп	

HEAD TYPE	CAPACITY PART DIAMETER	RANGE *		SHANKS	(A) FREE LENGTH	(B) TOOL BODY	(C) CUTTER SHANK	(D) MASTER PILOT	(E) REF MIN CUTTER LENGTH	(F) BORE DEPTH	(G) OVER TRAVEL	(H) Mounting	(J) REF TO FRONT NUT
		LUCATION	TRAVEL	0.750in/20mm	4.083 [103.70]		JIMIK	ø0.591 [ø15.0]	1.48			0.636	
	0.157–0.787	UP TO	0.197	No 2 MT	4.894 [124.32]	ø1.58	0.625			0.85	0.06		0.157
AKATO	[4.0–20.0]	1.250 [31.75]	[5.0]	SK40/CAT40	6.248 [158.70]	[ø40.0]	[15.88]		[37.6]	[21.60]	[1.5]	[16.16]	[4.0]
				BT40	5.657 [143.70]	1							
				1.000in/25mm	5.547 [140.90]								
		30–1.654 UP TO .0–42.0] 1.375 [34.93]	0.276 [7.0]	No 3 MT	5.796 [147.23]	ø2.56 [ø65.0]	1.000 [25.40]	ø1.416 [ø36.0]	2.03 [51.5]	1.19 [30.23]	0.06 [1.5]	1.048 [26.63]	0.187 [4.76]
	0.630–1.654			SK40/CAT40	7.713 [195.90]								
AKATO	[16.0–42.0]			SK50/CAT50	6.299 [160.00]								
				BT40	7.122 [180.90]								
				BT50	8.152 [178.90]								
				30mm/1.500in/40mm	6.591 [167.40]								
				SK40/CAT40	8.756 [222.40]								
<b>ARX</b> 20 0.86	0.866-2.992 [22.0-76.0]	UP TO 1.500 [38.10]	0.394 [10.0]	SK50/CAT50	7.343 [186.50]	ø3.15 [ø80.0]	1.250	ø1.772 [ø45.0]	2.43 [61.8]	1.46 [37.08]	0.12 [3.0]	1.294 [32.87]	0.224 [5.70]
			[10.0]	BT40	8.165 [207.40]	[20010]		[]	[0.10]				
				BT50	8.087 [205.40]								

\* The capacity range shown is *not* intended as an absolute limitation. It defines the normal range when using standard components. The diameter range represents the approximate part diameter. The groove location is the approximate distance to the groove measured from the end of the part.

# **Bill of Materials**

AR Series Automatic recessing

### **ARX** External Head



1 Master Pilot	8 Spring Plate	19 Back Plate Dowel	110 Micrometer Screw
2 Front Nut	9 Coolant Pipe	20 Spring Plate Pipe	111 Disc Springs
3 Back Plate	10 Micrometer Nut	21 Centralising Pin	112 Key
4 Standard Chip Guard	12 Over-rider Dowel	100 Set Screw	113 Torx Screw
4A Two Slot Chip Guard	13 Slipper	101 Double Angular Contact Bearing	115 Centralizing Screw
5 Front Body	14 Slipper Pin	104 Spring	
6 Toolslide	15 Copper Pad	108 Oiler	
7 Rear Body	16 Shank	109 Retaining Screw	

### ARX-S External Short-Length Head



The Feed Ratio is the ratio of spindle to radial cutter movement



#### INCH [METRIC]

HEAD TYPE	CAPACITY PART DIAMETER	Y RANGE . GROOVE LOCATION	MAXIMUM CUTTER TRAVEL	SHANKS	(A) FREE LENGTH	(B) TOOL BODY	(C) Cutter Shank	(D) Master Pilot	(E) REF MIN Cutter length	(F) TOOL SLIDE	(H) Mounting	(J) REF To front nut
APX10-S	0.157–0.787 [4.0–20.0]	UP TO	0.197 [5.0]	SK40/CAT40	5.705 [144.90]	ø1.58	0.625	ø0.591	1.48	0.85	0.636	0.157
		1.250 [31.75]		BT40	5.114 [129.90]	[ø40.0]	[15.88]	[ø15.0]	[37.6]	[21.60]	[16.16]	[4.0]
	RX16-S 0.630–1.654 UP TO [16.0–42.0] 1.375 [34.93]			SK40/CAT40	6.758 [171.65]							
<b>ARX</b> 16-S		UP TO 1.375 [34.93]	0.276 [7.0]	SK50/CAT50	5.345 [135.76]	ø2.56 [ø65.0]	1.000 [25.40]	ø1.416 [ø36.0]	2.03	1.19 [30.23]	1.048 [26.63]	0.187 [4.76]
				BT40	6.168 [156.66]				[51.5]			
				BT50	6.089 [154.66]							
				SK40/CAT40	7.461 [189.51]							
<b>ARX</b> 20-S [2	0.866–2.992	UP TO	0.394	SK50/CAT50	6.048 [153.61]	ø3.15	1.250	ø1.772	2.43	1.46	1.294	0.224
	[22.0–76.0]	1.500 [38.10]	[10.0]	BT40	6.870 [174.51]	[ø80.0]	[31.75]	[ø45.0]	[61.8]	[37.08]	[32.87]	[5.70]
				BT50	6.792 [172.51]							

\* The capacity range shown is *not* intended as an absolute limitation. It defines the normal range when using standard components. The diameter range represents the approximate part diameter. The groove location is the approximate distance to the groove measured from the end of the part.

# **Bill of Materials**

## ARX-S External Short-Length Head



# **ARJ** Jig-Type Head

# AR Series

Designed to run in a rotating bushing mounted in a jig plate. A tool for use on:

- Drill presses
- Jig boring machines
- Milling machines
- Radial arm drills
- Rotary transfer machines
- Special purpose machines
- Multi-head spindles

#### Features:

- Pilots off jig plate
- Workpiece must be rigidly clamped
- Micrometer stop controls depth of cut
- Axial location is controlled by tool adjustment or adjustable thrust housing
- Through-tool coolant is standard
- Overtravel shanks are standard





# **Operating Principle**

AR Series AUTOMATIC RECESSING

**ARJ** and **ARXJ** Recessing Heads operate according to the basic principles as illustrated below. The head type shown below is the **ARJ** model.



#### 1 Approach Stroke

The **ARJ** tool is rotating in a machine spindle and piloting in the bushing. The spindle is lowered.

#### 2 Feed Stroke

The adjustable thrust housing bottoms against the face of the rotating bushing. Downward pressure causes compression of the recessing head, thereby actuating the slide mechanism which feeds the cutter out radially into the work.

#### 3 End of Feed Stroke

The correct depth of cut is obtained when the micrometer stop nut bottoms against the tool body, making it impossible to continue the cut. Groove location is regulated by the adjustable thrust housing.

# **ARJ** Jig-Type Head



Running bushing is shown in operating position.



The Feed Ratio is the ratio of spindle to radial cutter movement

INCH	[METRIC]										
HEAD TYPE	APPROX. CAPACITY RANGE *	MAXIMUM CUTTER TRAVEL	SHANKS	(A) FREE LENGTH	(B) TOOL BODY	(C) CUTTER SHANK	(D) RUNNING Bushing	(E) REF MIN Cutter Length	( MINIMUM	F) Maximum	(G) OVERTRAVEL
			1.000in/25mm	7.640 [194.05]	ø3.12	ø0.394 [ø10.0]				4.78 [121.35]	
0.216 [5.5] ARJ10 0.984 [25.0]	0.216		No 3 MT	7.890 [200.40]							
	[5.5]	0.197	SK40/CAT40	9.805 [249.05]			ø2.677	1.08	2.42 [61.55]		0.06
	0.984	[5.0]	SK50/CAT50	8.392 [213.15]	[ø79.25]		[ø68.0]	[27.47]			[1.5]
	[25.0]		BT40	9.215 [234.05]							
		BT50	9.136 [232.05]								
		0.276 [7.0]	30mm/1.500in/40mm	8.937 [227.00]	ø3.91 [ø99.25]	ø0.630 [ø16.0]	ø3.937 [ø100.0]			5.14 [130.45]	
	0.590 [15.0]		SK40/CAT40	11.102 [282.00]							
<b>ARJ</b> 16			SK50/CAT50	9.687 [246.05]				1.54 [39.2]	2.48 [62.95]		0.12 [3.0]
	1.772 [45.0]		BT40	10.512 [267.00]							
			BT50	10.443 [265.00]							
			30mm/1.500in/40mm	8.972 [227.90]							
	0.866 [22.0]		SK40/CAT40	11.102 [282.00]							
<b>ARJ</b> 20		0.394 [10.0]	SK50/CAT50	9.724 [247.00]	ø4.51 [ø114.5]	ø0.787 [ø20.0]	ø4.331 [ø110.0]	1.84 [46.6]	2.70 [68.55]	4.76 [120.95]	0.12 [3.0]
	2.362 [60.0]		BT40	10.547 [267.90]							
	[00.0]		BT50	10.469 [265.90]							

\* The capacity range shown is *not* intended as an absolute limitation. The maximum diameter shown in the chart is defined as the suggested maximum groove diameter, dependent upon cutting forces, and intended for the sake of comparison only.

# **ARJ** Jig-Type Bushing





2 Spacer 101 Inner Ring

l

103 Grease Fitting

ME	TRIC	[INCH]

BUSHING No.	(A)	(B)	(B) (C) (D) (E) (F)		CAP HEAD SCREW		
<b>ARJ</b> 10–RB	ø45,0 [1.772]	ø67,975 [2.6726]	ø78,0 [3.071]	84,7 [3.335]	60,0 [2.362]	18,0 [0.709]	
<b>ARJ</b> 16–RB	ø65,0 [2.559]	ø99,975 [3.9360]	ø110,0 [4.331]	116,7 [4.594]	63,5 [2.500]	19,05 [0.750]	M6x1.0P (2 pieces)
<b>ARJ</b> 20–RB	ø80,0 [3.150]	ø109,975 [4.3297]	ø120,0 [4.724]	126,7 [4.988]	63,5 [2.500]	19,05 [0.750]	

# ARJ Jig-Type Head



2 Front Shell	12 Over-rider Dowel	104 Spring	111 Disc Springs
5 Front Body	13 Slipper	105 Caphead Screw	112 Key
6 Toolslide	14 Slipper Pin	106 Tool Clamp Screw	113 Caphead Screw
7 Rear Body	15 Copper Pad	107 Tool Adjust Screw	115 Centralizing Screw
8 Spring Plate	16 Shank	108 Oiler	
9 Coolant Pipe	20 Spring Plate Pipe	109 Retaining Screw	
10 Micrometer Nut	21 Centralising Pin	110 Micrometer Screw	

# **ARXJ** Heavy Duty Jig-Type Head

# **AR** Series Automatic recessing



A tool for use on:

- Drill presses
- Jig boring machines
- CNC machines
- Milling machines
- Radial arm drills
- Rotary transfer machines
- Special purpose machines
- Multi-head spindles

#### Features:

- Pilots off workpiece or jig plate
- Cutter mounted on end of tool slide for rigid support in heavy cuts
- Micrometer stop controls depth of cut
- Axial location controlled by adjustable thrust housing
- Through-tool coolant is standard
- Overtravel shanks are standard

# ARXJ Heavy Duty Jig-Type Head



HEAD TYPE	APPROX. CAPACITY RANGE *	MAXIMUM CUTTER TRAVEL	SHANKS	(A) FREE LENGTH	(B) Thrust Housing	(C) TOOL SLIDE	(D) TOOL BODY	(E) TOOL SLIDE	(F) MINIMUM	(G) OVERTRAVEL
			1.000in/25mm	7.640 [194.05]					1.76 [44.7]	0.06 [1.5]
	1.772		No 3 MT	7.890 [200.40]						
	[45.0]	0.197	SK40/CAT40	9.805 [249.05]	ø3.12	ø0.85 [ø21.6]	ø2.281	0.625		
AKASIO	3.15	[5.0]	SK50/CAT50	8.392 [213.15]	[ø79.25]		[ø57.925]	[15.875]		
	[80.0]		BT40	9.215 [234.05]						
			BT50	9.136 [232.05]						
		0.276 [7.0]	30mm/1.500in/40mm	8.937 [227.00]	ø3.91 [ø99.25]	ø1.19 [ø30.23]	ø3.120 [ø79.25]	1.000 [25.400]	2.415 [61.34]	0.12 [3.0]
	2.559 [65.0]		SK40/CAT40	11.102 [282.00]						
<b>ARX</b> J16	3.937 [100.0]		SK50/CAT50	9.687 [246.05]						
			BT40	10.512 [267.00]						
			BT50	10.433 [265.00]						
		0.394 [10.0]	30mm/1.500in/40mm	8.972 [227.90]			ø3.673 [ø93.30]	1.250 [31.750]	2.683 [68.15]	0.12 [3.0]
ARXJ20	3.150 [80.0]		SK40/CAT40	11.102 [282.00]						
			SK50/CAT50	9.724 [247.00]	ø5.00 [ø127.00]	ø1.46 [ø37.08]				
	5.000 [127.0]		BT40	10.547 [267.90]						
			BT50	10.469 [265.90]						

\* The capacity range shown is not intended as an absolute limitation. The maximum diameter shown in the chart is defined as the suggested maximum groove diameter, dependent upon cutting forces, and intended for the sake of comparison only.

# **Bill of Materials**

# ARXJ Heavy Duty Jig-Type Head



2 Front Shell	10 Micrometer Nut	20 Centralising Pin	110 Micrometer Screw
5 Front Body	12 Over-rider Dowel	21 Spring Plate Pipe	111 Disc Springs
6 Toolslide	13 Slipper	104 Spring	112 Key
7 Rear Body	14 Slipper Pin	105 Caphead Screw	113 Caphead Screw
8 Spring Plate	15 Copper Pad	108 Oiler	115 Centralising Screw
9 Coolant Pipe	16 Shank	109 Retaining Screw	

# Head Conversion

INTERCHANGEABILITY OF COMPONENTS

With the **AR** Series, we have refined the design of our complete system of automatic recessing heads so that many head types utilize some common components. **AR** Series heads come in three standard sizes, based upon the cutter shank diameter as expressed in millimeters: 10, 16, and 20. A prefix is added to the size in order to identify the particular head type (e.g., **AR**10, **ARJ**16, **ARX**20). Within a given size range, it may be possible to convert one head type into another style by merely changing a few parts.

The basic **AR** unit is a toolholder/insert-style head for internal grooving and recessing. While different versions of the heads are available to perform specific machining operations, each head can be converted to a different style of the same size by changing a few key components. A typical example (**AR**16 Recessing Head) is shown below. Some components within the head must be changed in order to accommodate various cutter styles. Please consult our customer service department if you have any questions regarding head conversions.



# Head Conversion

INTERCHANGEABILITY OF COMPONENTS

# **AR** Series Automatic recessing



ARX Recessing Head
■ External unit with external toolholder, cartridge, & pilot for O.D. grooving operations

# Interchangeability of Shanks

# AR Series

#### **AR** SERIES SHANKS

HEAD TYPE	STANDARD SHANKS
<b>AR</b> 10 <b>ARX</b> 10 <b>ARSP</b> 1	0.750 in. 20.0 mm No. 2 MT SK40 CAT40 BT40
<b>AR</b> 16 <b>ARJ</b> 10 <b>ARX</b> 16 <b>ARS</b> P2 <b>ARX</b> J10	1.00 in. 25.0 mm No. 3 MT SK40/SK50 CAT40/CAT50 BT40/BT50
AR20 ARJ16 ARJ20 ARX20 ARXJ16 ARXJ20	1.500 in. 30.0 mm 40.0 mm SK40/SK50 CAT40/CAT50 BT40/BT50

This chart lists standard stocked shanks for the complete **AR** series, with the exception of the short-length heads shown below. All shanks not listed are considered special; request a quotation.

#### **AR-S** SERIES SHANKS

HEAD TYPE	STANDARD SHANKS
<b>AR</b> 10-S <b>ARX</b> 10-S	SK40 CAT40 BT40
<b>AR</b> 16-S <b>ARX</b> 16-S	SK40/SK50 CAT40/CAT50 BT40/BT50
<b>AR</b> 20-S <b>ARX</b> 20-S	SK40/SK50 CAT40/CAT50 BT40/BT50

This chart lists standard stocked shanks for short-length **AR-S** series heads; these heads are available only with shanks as shown. (Short-length **AR-S** series heads are shorter versions of standard **AR** and **ARX** heads, restricted to use on CNC machining centers. Depth of cut is controlled by the Z-axis of the machining center.)

# **Pilots**

# AR Series

Pilots are required to locate and stabilize the recessing head in the component bore. All pilots are manufactured to suit the application. Although the basic design and dimensions are standardized as shown on page 33, the locating diameter of the pilot is designed specifically for your component. Part pilots are retained in the master pilot by three retaining screws.



# Specifications

PILOTS

# AR Series

#### MASTER PILOT

#### PART PILOT





Note: If machine lacks internal coolant capability, part pilot must be designed with coolant windows

INCH [ME	TRIC]					with cools	ant windows	
HEAD PILOTS	(ØA) 0003 [-0.008]	(B)	(ØC) MAX	(D) 005 [-0.13]	(ØE) 005 [-0.13]	(F)	(G)	(H)
ARSP-1	.5904 [14.995]	.394 [10.00]	.472 [12.00]	.098 [2.50]	.909 [23.10]	.394 [1.00]	.138 [3.50]	120°
ARSP-2	1.0896 [27.675]	.551 [14.00]	.969 [24.60]	.098 [2.50]	1.409 [35.80]	.394 [1.00]	.138 [3.50]	120°
<b>AR</b> 10 <b>ARX</b> 10	.5904 [14.995]	.500 [12.70]	.472 [12.00]	.100 [2.55]	.844 [21.45]	.394 [1.00]	.138 [3.50]	120°
<b>AR</b> 16 <b>ARX</b> 16	1.415 [35.95]	.551 [14.00]	1.295 [32.90]	.130 [3.30]	1.811 [46.00]	.394 [1.00]	.138 [3.50]	120°
<b>AR</b> 20 <b>ARX</b> 20	1.772 [44.99]	.748 [19.00]	1.63 [41.4]	.148 [3.75]	2.299 [58.40]	.394 [1.00]	.177 [4.50]	120°

ALL UNSPECIFIED DIMENSIONAL TOLERANCES ARE ±0.005 [0.13]

# **Piloting Methods**

Pilots on I.D. and stops on face of component.

 $\nabla$ 

Pilots and stops on fixture plate.

 $\overline{}$ 

Pilots on fixture plate and stops on face of component.





Pilots on O.D. and stops on face of component.



**AR** Series AUTOMATIC RECESSING

# Toolholders, Cutters, Inserts

Toolholders are designed to suit the application. The basic design of the toolholder is standardized (see page 36), but the diameter and length of the holder is designed to suit your component.

Toolholders with replaceable inserts are used where application parameters permit. As a general rule, toolholders for holes 9/16 inch (approx. 14.5mm) and larger utilize replaceable inserts. Cutters for smaller diameters are usually of brazed-carbide or high-speed steel construction.

Our improved toolholder design allows fast and easy incremental adjustment of axial groove location without removing the toolholder from the head.

Many inserts can be manufactured from standard blanks (see bottom of page 36.) Toolholders and inserts can be designed for back-chamfers, thread reliefs, multiple grooves, and special groove geometries; submit a part print and request a quotation. Toolholders can be designed with an internal coolant port where required (see example below).



Our improved toolholder design allows fast and easy incremental adjustment of axial groove location without removing the toolholder from the head.

(See set-up and operation guide on page 37 for more information)

# **Specifications**

TOOLHOLDER

# AR Series



METRIC [I	NCH]						0							
HEAD TYPE	(A)	(B)	(C)	(D)	(E)	(F)	(G) h11	(H)	(L)	(K)	ø(M)	(N) max	(P)	(R)
ARSP-1	10.00 [0.394]	12.70 [0.500]	0.50 [0.020]	9.00 [0.354]	1.50 [0.059]	3.00 [0.118]	0.70 [0.028]	2.30 [0.091]	3.35 [0.132]	8.00 [0.315]	3.00 [0.118]	0.50 [0.020]	9.50 [0.374]	0.70 [0.028]
ARSP-2	12.00 [0.472]	17.25 [0.679]	0.50 [0.020]	12.50 [0.492]	3.00 [0.118]	5.00 [0.197]	1.60 [0.063]	3.40 [0.134]	5.75 [0.226]	9.50 [0.374]	3.00 [0.118]	0.50 [0.020]	15.50 [0.610]	0.80 [0.031]
<b>AR</b> 10														
<b>AR-</b> S10	10.00 [0.394]	20.80 [0.819]	0.50 [0.020]	15.25 [0.600]	1.50 [0.059]	3.00 [0.118]	0.80 [0.031]	2.20 [0.087]	6.70 [0.264]	7.75 [0.305]	3.00 [0.118]	0.50 [0.020]	19.00 [0.748]	0.70 [0.028]
<b>ARJ</b> 10														
<b>AR</b> 16														
<b>AR-S</b> 16	16.00 [0.630]	29.50 [1.161]	0.50 [0.020]	19.50 [0.768]	3.00 [0.118]	5.00 [0.197]	1.60 [0.063]	3.40 [0.134]	6.10 [0.240]	12.50 [0.492]	4.00 [0.157]	0.50 [0.020]	26.50 [1.043]	0.80 [0.031]
<b>ARJ</b> 16														
<b>AR</b> 20														
<b>AR</b> -S20	20.00 [0.787]	36.30 [1.429]	0.50 [0.020]	25.40 [1.000]	5.00 [0.197]	6.00 [0.236]	1.75 [0.069]	4.25 [0.167]	10.00 [0.394]	15.50 [0.610]	5.00 [0.197]	0.50 [0.020]	33.30 [1.311]	1.00 [0.039]
<b>ARJ</b> 20														

#### **AR** Series Replaceable Inserts



Standard insert blanks



Replaceable carbide inserts are used where applications permit. Special or intricate geometries are available.
# Set-up

### **AR Series** AUTOMATIC RECESSING

There are four basic steps to the set-up of **AR** Series Automatic Recessing heads. (Set-up procedures differ somewhat for internal and external heads.)

### 1 Install pilot

For all head types except **ARJ**, the pilot must be installed in the head. The pilot will fit either directly into the sealed bearing or into a master pilot for quick and easy tool changes.

### 2 Install cutter/toolholder

The cutter normally comes in three different styles:

- High-speed steel cutter
- Tungsten carbide brazed-tip cutters
- Replaceable-insert toolholders

For internal recessing heads, install the cutter in the head with the cutting edge pointing in the direction of cut (i.e., in the direction of toolslide movement). The cutter is clamped and fixed in position by two set screws in the head. The cutter must be positioned radially in the head so that the cutting edge will be on center as the tool moves out to cut. This is facilitated by the use of a key in the cutter shank, which automatically aligns the cutting edge on center.

For external recessing heads, install the toolblock onto the toolslide and secure in place with two caphead screws. An adjustable cartridge is fitted to the toolblock and held in place by a buttonhead screw. An inexpensive, replaceable insert is fitted to this cartridge and secured in place by an insert screw. The cutting edge of the insert is automatically aligned on center as the toolblock is secured to the head.

For **ARXJ** heads, install a fixed cartridge onto the end of the toolslide and secure in place with caphead screws. Replaceable inserts can be fixed to this cartridge with insert screws. The cutting edge is automatically aligned on center as the cartridge is secured in the head.



### **3** Set cutter projection from pilot

For all head types except **ARJ** and **ARXJ**, the projection of the cutter from the pilot must be set properly in order to achieve accurate groove location.

For internal recessing heads, groove location is controlled by the tool adjustment set screw, which is located in the toolslide. The tool adjustment screw is accessed through a hole in the chip guard on the front shell. Insert the toolholder until it bottoms out in the toolslide. Tighten tool adjustment screw and move cutter out until the set dimension (between cutter and pilot) is achieved. Then lock the cutter in place by tightening the locking set screws.

For external recessing heads, groove location is controlled by a set screw in the end of the adjustable cartridge that is mounted on the toolblock. Once the groove location is set, lock the cartridge in place with the buttonhead locking screw.

For **ARJ** and **ARXJ** heads, groove location is controlled by an adjustable thrust housing on the externally threaded front body. **ARJ** heads have both the tool adjustment screw and the adjustable thrust housing for infinite cutter control.

# Set-up

### 4 Depth of cut/tool travel

For all head types except AR-S and ARX-S (short length heads), depth of cut is controlled by a micrometer nut that allows the head to pre-set off the machine. The standard tool feed ratio for all heads is 2:1 (i.e., the ratio of spindle to radial cutter movement).

Refer to the drawing supplied with the tool for the set-up dimension. If the drawing is unavailable, follow this procedure: Add the depth of cut (the distance from the I.D. of the bore to the bottom of the groove) to the clearance between the cutter and the I.D of the bore. Multiply this figure by the feed ratio (i.e., multiply by 2 for standard feed ratio) in order to arrive at the distance to set the micrometer nut from the front body. This distance should be set using gauge blocks or by fine-tuning the micrometer nut position manually to achieve the desired groove depth.

is controlled by the Z-axis of the CNC machining center.

### **AR** Series AUTOMATIC RECESSING

HEAD TYPE	MICROMETER NUT SCREW	INSERT TOOL HOLDER (LENGTH ADJ.)	MASTER PILOT
<b>AR</b> 10	1.5mm	2.0mm	1.5mm
<b>AR</b> 16	3.0mm	3.0mm	1.5mm
<b>AR</b> 20	4.0mm	4.0mm	2.0mm
ARSP-1	1.5mm	1.5mm	1.5mm
ARSP-2	2.5mm	2.5mm	1.5mm

#### HEX WRENCHES REQUIRED FOR ADJUSTING **AR** HEADS

Approximate adjustment gap for all internal recessing heads, when tool is in set position.



# Operation

# Speeds & Feeds

Please refer to the charts below for *speed and feed recommendations* for specific material types. The charts are intended as a guide or starting point; the actual speed and feed used will depend on a number of factors, including type of machine, condition of machine spindle, rigidity of fixturing, type of coolant used or dry cutting, tool length, cutter geometry, interrupted cut, etc.

INCH							
MATERIAL	CUTTING SI	PEED (FT/MIN)	FEED RATE	(INCHES/REV)	TOP RAKE (DEGREES)		
	HSS	Carbide	HSS	Carbide	HSS	Carbide	
Aluminum	200—300	400—700	.002—.005	.002—.005	10—15	8—12	
Brass	100—200	200—525	.002—.005	.002—.005	0—3	0—3	
Bronze	50—130	100—400	.002—.005	.002—.005	3—5	3—5	
Cast Iron	50—90	100—180	.002—.004	.002—.005	0—3	0—3	
Copper	100—200	200—400	.002—.004	.002—.005	10—15	8—12	
Magnesium	200—300	400—700	.004—.006	.004—.006	10—15	8—12	
Malleable Cast Iron	50—90	100—200	.002—.004	.003—.005	0—3	0—3	
Resin (Plastic)	70—135	160—400	.004—.006	.004—.006	10—15	8—12	
Free Cutting Steel	70—100	100—230	.002—.004	.003—.005	5—10	4—8	
Annealed Steel	50—70	100—200	.002—.004	.003—.005	5—8	3—6	
Wrought Steel	35—70	85—220	.002—.003	.003—.004	5—8	3—6	
Alloy Steel	35—70	85—220	.002—.003	.003—.004	4—6	3—6	
Tool Steel	35—50	85—150	.001—.002	.002—.003	4—6	3—6	
Monel & Stainless	85—135	150—250	.001—.003	.002—.004	10—20	8—12	

#### METRIC

MATERIAL	CUTTING SPEED (M/MIN)		FEED RAT	E (MM/REV)	TOP RAKE (DEGREES)		
	HSS	Carbide	HSS	Carbide	HSS	Carbide	
Aluminum	60—90	120—210	0,05—0,13	0,05—0,13	10—15	8—12	
Brass	30—60	60—160	0,05—0,13	0,05—0,13	0—3	0—3	
Bronze	15—40	30—120	0,05—0,13	0,05—0,13	3—5	3—5	
Cast Iron	15—25	30—55	0,05—0,10	0,05—0,13	0—3	0—3	
Copper	30—60	60—120	0,05—0,10	0,05—0,13	10—15	8—12	
Magnesium	60—90	120—210	0,10—0,15	0,10—0,15	10—15	8—12	
Malleable Cast Iron	15—25	30—60	0,05—0,10	0,08—0,13	0—3	0—3	
Resin (Plastic)	20—40	50—120	0,10—0,15	0,10—0,15	10—15	8—12	
Free Cutting Steel	20—30	30—70	0,05—0,10	0,08—0,13	5—10	4—8	
Annealed Steel	15—20	30—60	0,05—0,10	0,08—0,13	5—8	3—6	
Wrought Steel	10—20	25—65	0,05—0,08	0,08—0,10	5—8	3—6	
Alloy Steel	10—20	25—65	0,05—0,08	0,08—0,10	4—6	3—6	
Tool Steel	10—15	25—45	0,03—0,05	0,05—0,08	4—6	3—6	
Monel & Stainless	25—40	45—75	0,03—0,08	0,05—0,10	10—20	8—12	

# Operation

#### (continued)

# Coolant

Regarding the use of coolant, follow normal machine shop procedures for the cutter material and the material to be machined.

## Lubrication

1 We recommend a water resistant grease for use in these heads. Kluber Altemp Q NB50 has been thoroughly tested and found to perform exceptionally well – it is the only grease we recommend. It should be applied to all moving parts and surfaces when the head is disassembled for cleaning and maintenance, or if the head will be stored for extended periods. Disassembly and cleaning should be done periodically.

2 To lubricate the heads during use, apply Kluber Altemp Q NB50 grease through the external oilers or grease fittings on the head. This should be done on a weekly basis, or more frequently if necessary. Lubrication frequency can vary depending on the working environment, operational speed, coolant used, and number of cycles. Remember, adequate lubrication is vital to long head life and trouble-free performance.

3 A high-pressure hand pump lube gun is available from Cogsdill to make routine maintenance easy. (Ref. Part No. CN-D24)

# Applications

## AR10 Internal Recessing Head

performing an I.D. grooving operation; pilots in part



# **ARSP1** Internal Recessing Head

machining an I.D. groove with a radius on a banjo fitting; pilots in part



## AR20 Internal Recessing Head

machining a back-spotface with an I.D. chamfer; pilots in part



# AR16 Internal Recessing Head

performing an I.D. grooving operation; pilots in fixture plate



# **Applications**

### **ARX10** External Recessing Head

performing an O.D. grooving operation; pilots on part O.D. and includes balance weight



### **ARX**16 External Recessing Head

machining a face and a double groove on an O.D.; pilots on part O.D.



# ARJ10 Jig-Type Recessing Head

machining snap ring groove on each end of a 6-foot-long part



# Special Recessing Head

machining three grooves simultaneously



# Nobur<sup>®</sup> JA/JC Series

# Nobur<sup>®</sup> JA Recessing Head

For deep bore recessing and grooving.

- A tool for use on:
- Drill presses
- Jig boring machines
- Milling machines
- CNC machines
- Tool or turret lathes
- Horizontal boring machines
- Special purpose machines

#### Features:

In-bore pilot supports cutter along its entire length – eliminates tool deflection; ensures concentricity through rigid cutting action

- Micrometer-stop adjustment
- Multiple grooves, chamfers, or metering lands
- O-ring and retaining ring grooves
- Relief grooves and tube sheet grooves
- Back-chamfering and facing of deep bores

### Nobur® JA2000 Recessing Head

For deep bore recessing and grooving. Designed for heavier cuts than the regular **JA**. Innovative internal coolant system directs coolant to cutting edges for improved chip evacuation, longer tool life, better tool function, and improved repeatability. For use on machines with internal coolant capability. \*

#### Features:

Same in-bore pilot support and micrometer-stop adjustment as the regular **JA** 

Capable of wider cuts than the regular **JA** in some applications

Extremely durable high-load precision dual bearings for long life

Easy disassembly and reassembly for maintenance

Overtravel units available upon request

\* **JA**2000 Recessing Heads can be ordered in a Side-Port model for use on machines that do not have through-spindle coolant capability. Through-shank coolant is standard; specify side-port coolant if desired.

# **Operating Principle**



### 1 Approach Stroke

The **Nobur**<sup>®</sup> **JA** tool is rotating in a machine spindle. The spindle is lowered. The tool approaches entry into the bore.

### 2 Feed Stroke

The pilot is located in the bore, stopping against the face of the workpiece. Downward travel of the machine spindle compresses the tool so that the cutter feeds out radially into the surface of the workpiece. The pilot rigidly supports the cutter along its entire length to eliminate deflection and ensure concentricity.

### 3 End of Feed Stroke

Radial depth of cut is obtained when the micrometer-stop nut bottoms out. Groove location is controlled by the adjusting stopcollar, which moves the nosepiece up or down to position the cutter arm for accurate groove location.

# **Specifications**





The Feed Ratio is the ratio of spindle to radial cutter movement

HEAD TYPE	CAPA	CITY <sup>1</sup>	(/ _ FR	A) REE	. (1	B)	. ((	C)	I) MAXI	D) IMUM	() MINI	)) MUM	(E) SHANKS <sup>2</sup>	. (1	F)
	in .	mm	in	mm	in	mm	in	mm	In	mm	in	mm	o ( 111	in	mm
	0.25	6.300	3.82	97.00	2.28	57.90	2.06	52.30	2.24	56.90	1.24	31.50	3/4" straight 3	3.25	82.60
	1.85	47.10											1"–12 acme	3.63	92.20
JA													1-1/16"–12 acme	3.63	92.20
													#2 morse taper	3.19	81.00
													#3 morse taper	3.88	98.60
10,0000	0.25	6.300	4.43	112.5	3.36	85.40	3.00	76.20	1.53	38.90	1.03	26.20	1" straight 4	3.00	76.20
<b>JA</b> 2000	1.85	47.10											Ũ		
	1.00	25.40	6.47	164.3	4.97	126.2	4.50	114.3	3.60	91.40	2.37	60.20	1-1/2" straight	4.63	117.6
JC	3.79	96.30											#3 morse taper	3.94	100.0
													#4 morse taper	4.88	124.0
													"+ morse taper	4.00	12.4.0

1 Capacity means the suggested maximum groove diameter. Dependent upon cutting forces and bore diameter. Stated capacity is for steel.

2 Shank is included with head. Shanks other than shown can be supplied upon request.

3 Supplied with through-tool coolant.

4 Through-shank coolant is standard; specify side-port coolant if desired.

# Nobur<sup>®</sup> JA Recessing Head



- 1 Body Holder **5** Bearing Assembly 9 Stop Collar-Adjustment 10 Retainer Ring-Insert 2 Adjustment Nut 6 Collar Hub Mounting Assembly 3 Snap Ring
  - 8 Screw Locking-Housing

4 Housing-Bearing

Stop Collar

- 7 Leaf Spring (Quantity 3) 11 Lock Screw
  - 12 Retainer Loop

- 13 Pin
- 14 Spacer/Bushing/ Spring
- **15** Compression Spring Return

49

# **Bill of Materials**

# Nobur<sup>®</sup> JA2000 Recessing Head



NOTE: Coolant location can be changed in the field; consult Sales Department.

1 Spindle	8 Stop Nut	15 Cone Point Screw	22 Retaining Ring
2 O-Ring	9 Socket Head Cap Screw	16 Leaf Spring	Details 23 thru 27 optional
3 Compression Spring	10 Bearing Sleeve	17 Coolant Tube	23 Outer Bearing Spacer
4 Spacer Bushing	11 Ball Bearing	18 Housing	24 Inner Bearing Spacer
5 Pin	12 Outer Bearing Spacer	19 Flat Point Set Screw	25 O-Ring
6 Drive Pin	13 Inner Bearing Spacer	20 Bearing Retainer	26 Coolant Nipple
7 Flat Point Set Screw	14 Bearing Collar	21 Stop Collar	27 Pipe Plug (not shown)

# Nobur<sup>®</sup> JC Recessing Head



1 Body Holder	6 Bearing	11 Screw	16 Pad-Spring Retaining
2 Adjustment Nut Rear	7 Housing-Bearing Stop Collar	12 Leaf Spring-Bottom	17 Pin
3 Screw	8 Screw	13 Retainer Collar	18 Assembly Pull Yolk
4 Snap Ring	9 Leaf Spring-Upper	14 Screw	19 Compression Spring
5 Snap Ring	10 Stop Collar Adjustable	15 Screw	20 Transport Sleeve

# Set-up

# Nobur<sup>®</sup> JA/JC Series

Cogsdill **Nobur**<sup>®</sup> **JA/JC** tools are easily set. Since the precision feed motion is built into the head, only two adjustments are required in order to properly set up a tool for operation. Occasionally, compensating adjustments might be required if there is an error in the initial settings, or to compensate for cutter wear. However, by following the steps prescribed below, it will be easy to attain the initial set-up.

### 1 Set front stop collar

This setting determines the position of the groove(s) relative to the face of the part, or other surface from which the tool actuates. Simply adjust the threaded stop collar, measuring from the face of the collar to the top corner of the cutter until the correct distance is established (refer to photo A). Once set, the locking screw on the outer tool body should be tightened.

### 2 Set the groove diameter to be cut

On manually fed machines, this setting is established by adjusting the threaded diameter stop nut at the rear of the tool body. Because the cutter motion is radial, the groove cut diameter can be measured by using a micrometer to measure directly across the pilot and cutting edge when the head is compressed (refer to photo B). Since the pilot is .002 in. (0.05mm) under the smallest bore diameter, the cutter should project from the pilot for a distance equal to the required depth of cut. An alternative setting method is to measure the projection of the cutter using a surface plate indicator relative to the centerline of the bore.

Setting the groove diameter for machines with power feed requires that the diameter stop nut be backed away (toward the rear of the tool) so that it becomes nonoperative. Tools with Acme-threaded shanks do not have the diameter stop nut. The automatic feed on the machine is then set to produce the cutter projection required to cut the desired groove diameter. Preset holders and gauges may also be used to establish the spindle travel limits.



Since cutter deflection is eliminated due to the support of the cutter by the arm and pilot, no compensation is required. Once the above settings are verified, the tool is ready to use. However, please remember that variations in bore diameter can cause groove dimensions to vary. A variation of .001 in. (0.02mm) in bore diameter can result in a .002 in. (0.05mm) variation in groove diameter. Therefore, bore tolerances must be limited to less than 1/2 of the tolerance required for the groove diameter. If this tolerance requirement presents a problem, it might be necessary to pilot the tool in a fixture instead of piloting in the bore. The diagram on page 53 shows how to measure a tool to cut a specific diameter.



# Set-up and Operation

Nobur<sup>®</sup> JA/JC Series AUTOMATIC RECESSING DEEP HOLE

#### (continued)

#### **Diameter Setting Methods**



In order to measure for a specific groove cut diameter, the tool must be actuated to the limit setting by compressing the actuating assembly against the diameter stop nut. The nominal clearance between the pilot diameter and the minimum bore diameter is .002" (.05mm).

#### **Tool Operation**

Cogsdill **Nobur**<sup>®</sup> **JA/JC** Recessing tools operate automatically as axial spindle travel is converted into radial cutter travel within the head. The pilot enters the bore and the stop collar contacts the front of the part. Continued spindle travel results in corresponding cutter travel which is rigidly supported within the part for extreme accuracy. A sealed bearing between the tool body and the stop collar prevents marking of the workpiece.

Radial cutter advancement is approximately 1/2 of spindle travel. Depth of cut is precisely controlled by an adjustable diameter stop nut located on the back end of the tool. A feed rate of .003–.005 IPR (0.08–0.13mm) is generally used.

Upon completion of the cut, tool withdrawal feed should be at the cutting feed rate until the stop collar no longer contacts the part. This will ensure that the cutter has fully retracted into the pilot before the tool is withdrawn from the part.

#### **Tool Lubrication**

In applications where water soluble or synthetic coolants are used, we recommend that, when the machine and tool are idle, the tool be removed from the spindle and immersed in oil to keep it lubricated and to prevent rusting of the internal mechanism.

# Applications

## Nobur<sup>®</sup> JA Recessing Head

machining eight metering lands in one pass



# Nobur<sup>®</sup> JA Recessing Head

performing grooving operation with piloting area in advance of cut



# Nobur<sup>®</sup> JA Recessing Head

back-cutting five locations



# overview

# Generating Heads

For facing, recessing, boring, and contouring. Multiple operations can be performed faster, more economically, with better quality, and at one spindle location. Used on special-purpose machines and other high production machinery, including transfer lines and dial machines.

- Single or double-slide models are available, designed for feed-out or feed-in
- Sizes from 100 to 250mm (3.937 to 9.842 in.) in diameter
- Drawbar actuation- no need to pilot in part or fixture
- Unique actuator design- smooth, accurate motion for precise repeatability
- Internal mechanism manufactured to exacting tolerances- backlash is virtually eliminated
- All moving parts are hardened and precision ground for lasting accuracy
- Built-in lubeways and easily accessible grease fittings
- Equipped with through-tool auto lube capability
- Special lightweight slides are available (optional) for higher cutting speeds and shorter cycle timestooling can be balanced



Custom-designed top tooling is mounted in qualified holes on the toolslide. Standard inserts are used for most applications. Special head designs and special form cutters are available.

Cogsdill generating heads are designed to work on machines where the tool slide stroke is controlled by a drawbar. The drawbar can produce finite, accurate movements in the tool slide(s), allowing the head to perform accurate machining operations. Drawbars can either push or pull on the actuator, and may be controlled by CNC, hydraulic, or mechanical action. Operations such as boring, turning, facing, chamfering, and form cutting can be easily performed. Generating heads can often be made to perform multiple operations in a single pass – this provides for optimum efficiency and performance in your machining operations.

Cogsdill generating heads are made from the highest quality materials, to exacting quality standards. Our engineers have built in quality features that ensure durability and consistent accuracy. These high-quality features include hardened and ground components, multiple grease fittings with internal lube ways, and anti-friction coatings on wear surfaces.

# **Operating Principle**



The method of operation incorporated in all Cogsdill generating heads is based on the principal of a sliding inclined wedge. This actuation mechanism produces smooth, linear cutter movement with little or no backlash.



Generating Head sliding inclined wedge mechanism and lubeways SHOWN ABOVE

# **Operating Principle**

### Generating HEADS

Cogsdill generating heads can be utilized on a variety of drawbar-equipped machines such as transfer lines, rotary transfer (dial type) machines, and other special purpose machines. The heads can be mounted on virtually any spindle that has a drawbar. Cogsdill can provide a complete tooling package for new machines, as well as for retrofitting an existing machine.



This typical component requires three machining operations: a face, an I.D. groove, and an O.D. chamfer. All operations will be completed at one station with one pass of the Cogsdill generating head. Drawbar stroke on the machine will control cutter movement.



The part is in position. The rotating machine spindle moves the generating head toward the part to begin the operation sequence. The drawbar and cross slide are in the home position.



### 2

The head is now in position. The drawbar begins to pull, causing the cross slide and cutters to move radially across the part as the cutting stroke begins. The face is cut first, followed by the I.D. groove, and then the O.D. chamfer.



### 3

The head is now at full drawbar stroke, and the cuts have been completed. The drawbar is then pushed back to the home position, thereby retracting the cutters. The spindle then retracts and the head is pulled away from the part and returned to the position shown in step one.

# Features & Options

Cogsdill generating heads are available as standard products in **single-slide** and **double-slide** models, ranging in diameter from 100mm to 250mm (approximately 4 to 10 inches). The head type used generally depends on the operation(s) being performed and the speed at which the head is run. Top tooling packages can be designed by our engineers to suit individual requirements. Specially designed heads are available when required to meet unique part requirements or production challenges.

#### Auto-lube

Our auto-lube feature enhances the longevity of the generating head by ensuring that all parts are consistently lubricated. Every Cogsdill generating head comes with auto-lubrication capability as a standard feature. Lubrication is fed to the head through the drawbar and actuator shaft. This feature can add many thousands of cycles to the life of the head, while eliminating the need to perform manual lubrication on a daily basis. Installation is easy on machines with spindles that have through-lube capability.

Most commercial auto-lube systems installed on machines are more than adequate for use with Cogsdill generating heads. The heads are usually lubricated automatically several times per shift, depending on the type of lubrication system available. When used in conjunction with an oil mist system (ISO68 grade oil), the flow rate is usually adjusted to a moderately low setting. For specific questions regarding the auto-lube feature, please consult with our engineering group.

#### Lubrication Recommendations

All heads may be manually lubricated via grease fittings in the main body if a through-lube system is not available on your machine. If these heads are not used with an automatic lubrication system, it is necessary to manually lubricate them at least weekly. More frequent lubrication may be necessary depending on the operational speed, type of coolant used, rapid cycling, and other factors. **Kluber Altemp Q NB50** has been thoroughly tested and found to perform exceptionally well – it is the only grease we recommend. Using a grease gun, inject one or two pumps of grease into each grease fitting.

#### Remember, adequate lubrication is vital to long head life and trouble-free performance.

It is also recommended that Kluber Altemp Q NB50 grease be applied to all moving parts and surfaces when the head is disassembled for maintenance and cleaning, or if the head is to be stored for extended periods.

(Note: if the head is being used with an oil mist automatic lube system, do not use the Kluber grease during disassembly and cleaning. Instead, use the same recommended ISO68 oil that is fed through the lube system. It is important not to mix the oil and grease – only one type of lubrication should be used at any one time.) A high-pressure hand pump gun is available from Cogsdill to make routine maintenance easy. (Ref. Part No. **CN-D24**)

#### **Actuation Ratios**

The standard actuation ratio for our heads is based on a 40-degree actuation angle. Slide travels for the standard actuation ratio are shown in the specification charts on the following pages.

Special actuation ratios are available to accommodate unique applications (e.g., when an extremely short tool stroke is required). Please consult with our engineering group when a non-standard ratio is required.

#### Adapter Plates

The bolt pattern in Cogsdill generating heads will fit a variety of spindles. However, when using a standard head, it may be necessary to use an adapter plate to mount the head due to different bolt patterns in the head and spindle. Cogsdill can design and manufacture adapter plates, when needed, to ensure accurate mounting of the head on any spindle. Special bolt patterns can also be built into specially designed heads.

#### Top Tooling Packages/Counterbalance Weights

Cogsdill can provide full top tooling packages for your application. Standard ISO / ANSI inserts are used where possible. Special form inserts are supplied where required.

When using a double-slide head, the slides move in opposing directions. This allows the head to be balanced by mounting a counterbalance to the slide opposite the one with the cutting tool. The weight moves proportionately to the cutting edge, thus producing a balanced cut. (In doubleslide applications where tooling is mounted on both slides, the tooling can be balanced.) Balance is particularly important as the size of the head, or the rotational speed, increases. The head can be dynamically balanced to a specific cut diameter and speed. (Single-slide heads are generally not balanced).

# Features & Options

#### (continued)

#### **Drawbar Force Requirements**

The drawbar force required to actuate the generating head is dependent upon three variable but interrelated factors:

- Size of generating head
- Spindle speed or cycle time requirement
- Weight of top tooling

As the size of the head increases, so does the required drawbar force. Cycle time requirements can also directly affect the spindle speed. In some cases, the use of high strength aluminum alloy cross slide(s) and/or top tooling may be necessary to keep the drawbar force requirements within the operational limits of the machine (see next section below).

Due to variations in top tooling weight, it is difficult to predict the actual drawbar force required to operate a generating head in a given application until a thorough layout is completed. When submitting a generating head application for quotation, please provide the following information in addition to part prints and general machine specifications:

- Spindle speed range available for your machine
- Desired cycle time (if known) for the operation(s) to be performed
- Drawbar actuation method (i.e. mechanical, CNC, or hydraulic) and force available

Our engineering department will recommend the appropriate generating head, and will quote a complete tooling package to suit your requirements.

#### Lightweight Cross Slides and Top Tooling

When application requirements demand head operation at higher than normal speeds, Cogsdill engineers can specify a special lightweight, high strength, aluminum alloy for manufacturing cross slides and some top tooling. The use of this alloy reduces the rotational mass of the head, allowing the tool to be run at higher speeds without significantly affecting the drawbar force requirement for actuating the head.

#### **Requests for Quotation**

All quote requests should be submitted through our customer service department.

While most heads sold are standard heads, each application tends to be unique. In order for our engineers to prepare a formal and complete quotation, we need to know as much as possible about your application. In order to assure that we have the necessary data for quoting, please submit the following:

Generating

HEADS

- A copy of the Application Data Sheet in the back of this catalog, filled out as completely as possible (material type, operations required, how the parts will be fixtured, etc.).
- A complete part drawing, and machine and spindle data. Please include spindle speed range, drawbar actuation method, and available drawbar force (if known).

#### Other important information includes:

- Does the application require a head that feeds in or feeds out?
- What actuation ratio is required (if known)? (If unknown, our engineers will gladly make recommendations.)
- Single or double slide?
- What type of drawbar fitting?
  (I.e. male or female, thread size and pitch. Male is standard, female is available on request.)
- Is through-lube capability available on the machine spindle?
- What is your production volume requirement?
- What is the desired machining cycle time for the operations involved (if known)?

Our customer service personnel will be pleased to assist you in answering questions about your application.

# **Specifications**



# Single-Slide Head



#### INCH [METRIC]

HEAD TYPE	(A)	(B)	(C)	(D)	(E)	(F <sup>h5</sup> )	(G)	(H)	(L)	(K <sup>H7</sup> x DP)	(L1)	(L <sub>2</sub> )
CN100SA	3.937 [100]	1.969 [50]	0.236 [6]	1.772 [45]	0.394 [10]	1.260 [32]	0.984 [25]	0.630 [16]	1.181 [30]	0.315 x 0.118 [8 x 3]	0.669 [17]	0.433 [11]
<b>CN</b> 125SA	4.921 [125]	2.283 [58]	0.315 [8]	1.969 [50]	0.394 [10]	1.772 [45]	1.181 [30]	0.787 [20]	1.575 [40]	0.315 x 0.118 [8 x 3]	0.984 [25]	0.512 [13]
CN160SA	6.300 [160]	2.756 [70]	0.374 [9.5]	2.362 [60]	0.394 [10]	3.937 [100]	1.378 [35]	0.984 [25]	1.969 [50]	0.394 x 0.157 [10 x 4]	1.181 [30]	0.630 [16]
CN200SA	7.874 [200]	3.346 [85]	0.472 [12]	2.756 [70]	0.394 [10]	5.315 [135]	1.969 [50]	1.260 [32]	2.756 [70]	0.472 x 0.157 [12 x 4]	1.772 [45]	0.787 [20]
CN250SA	9.843 [250]	3.937 [100]	0.591 [15]	3.543 [90]	0.394 [10]	6.300 [160]	1.969 [50]	1.260 [32]	3.543 [90]	0.472 x 0.157 [12 x 4]	2.362 [60]	0.787 [20]
INCH [ME	TRIC]											
HEAD TYPE	(M x P/LH)	(N <sup>h7</sup> )	(Q x P)	(R)	(S)	(T)	(U <sup>m5</sup> )	(V)	(W x P)	(X)	(Y)	(Z)
CN100SA	M10 x 1.0	0.472 [12]	M5 x 0.8	0.315 [8]	0.669 [17]	0.197 [5]	0.315 [8]	1.575 [40]	M8 x 1.25	2.756 [70]	0.669 [17]	0.795 [20.2]
<b>CN</b> 125SA	M10 x 1.0	0.551 [14]	M6 x 1.0	0.315 [8]	0.748 [19]	0.236 [6]	0.394 [10]	1.969 [50]	M10 x 1.50	3.543 [90]	0.866 [22]	1.031 [26.2]
CN160SA	M12 x 1.5	0.709 [18]	M8 x 1.25	0.394 [10]	0.984 [25]	0.256 [6.5]	0.472 [12]	2.559 [65]	M12 x 1.75	4.724 [120]	1.181 [30]	1.406 [35.7]
CN200SA	M16 x 1.5	0.709 [18]	M10 x 1.5	0.394 [10]	0.984 [25]	0.394 [10]	0.630 [16]	3.346 [85]	M12 x 1.75	6.300 [160]	1.575 [40]	1.878 [47.7]
CN250SA	M16 x 1.5	0.709 [18]	M12 x 1.75	0.394 [10]	0.984 [25]	0.472 [12]	0.787 [20]	3.937 [100]	M16 x 2.0	7.480 [190]	1.969 [50]	2.346 [59.6]

# **Bill of Materials**

Generating HEADS

## Single-Slide Head





7 Keeper Plate 1 Cross-slide 13 Caphead Screw 19 Location Dowel 2 Slide Block 8 Slide Block 14 Grease Nipple 24 Spring Washer 3 Body 9 Locknut 15 Dog Point Screw 4 Key 10 Drive Dowel 16 Head Screw 5 Actuator 11 Lock Screw 17 Spring Plunger 6 Key 12 Caphead Screw 18 Wiper

Generating HEADS

### **Double-Slide Head**



#### INCH [METRIC]

**CN250DA** 

0.709

M16 x 1.5

0.394

M10 x 1.5

0.984

HEAD TYPE	(A)	(B)	(C)	(D)	(E)	(F <sup>h5</sup> )	(G)	(H)	(L)	(K <sup>H7</sup> x DI	P) (L	_1)	(L2)
<b>CN</b> 100DA	3.937 [100]	1.969 [50]	0.236 [6]	1.772 [45]	0.394 [10]	1.260 [32]	0.984 [25]	0.630 [16]	0.630 [16]	0.236 x 0.11 [6 x 3]	8 1.1 [2	02 8]	0.394 [10]
CN125DA	4.921 [125]	2.283 [58]	0.315 [8]	1.969 [50]	0.394 [10]	1.772 [45]	1.181 [30]	0.787 [20]	0.787 [20]	0.315 x 0.11 [8 x 3]	8 1.3 [3	339 4]	0.512 [13]
<b>CN</b> 160DA	6.300 [160]	2.756 [70]	0.374 [9.5]	2.362 [60]	0.394 [10]	3.937 [100]	1.378 [35]	0.984 [25]	0.984 [25]	0.315 x 0.11 [8 x 3]	8 1.7 [4	72 5]	0.630 [16]
CN200DA	7.874 [200]	3.346 [85]	0.472 [12]	2.756 [70]	0.394 [10]	5.315 [135]	1.969 [50]	1.260 [32]	1.260 [32]	0.315 x 0.11 [8 x 3]	8 2.1 [5	26 4]	0.787 [20]
CN250DA	9.843 [250]	3.937 [100]	0.591 [15]	3.543 [90]	0.394 [10]	6.300 [160]	1.969 [50]	1.260 [32]	1.772 [45]	0.394 x 0.15 [10 x 4]	7 2.7 [7	'56 0]	0.787 [20]
INCH [ME	TRIC1												
HEAD TYPE	(M x P/LH)	(N <sup>h7</sup> )	(Q x P)	(R)	(S)	(T)	(U <sup>m5</sup> )	(V)	(W x P)	(X1)	(X <sub>2</sub> )	(Y)	(Z)
HEAD TYPE	(M x P/LH) M10 x 1.0	(N <sup>h7</sup> ) 0.472 [12]	<b>(Q x P)</b> M6 x 1.0	(R) 0.315 [8]	<b>(S)</b> 0.669 [17]	(T) 0.197 [5]	<b>(U<sup>m5</sup>)</b> 0.315 [8]	(V) 1.575 [40]	(W x P) M8x125	(X1) 1.811 [46]	(X2) 2.441 [62]	(Y) 0.669 [17]	(Z) 0.795 [20.2]
HEAD TYPE CN100DA CN125DA	(M x P/LH) M10 x 1.0 M12 x 1.5	(N <sup>h7</sup> ) 0.472 [12] 0.551 [14]	(Q x P) M6 x 1.0 M8 x 1.25	(R) 0.315 [8] 0.315 [8]	(S) 0.669 [17] 0.748 [19]	(T) 0.197 [5] 0.236 [6]	(U <sup>m5</sup> ) 0.315 [8] 0.394 [10]	(V) 1.575 [40] 1.969 [50]	(W x P) M8x125 M10x1.5	(X1) 1.811 [46] 2.087 [53]	(X <sub>2</sub> ) 2.441 [62] 2.992 [76]	(Y) 0.669 [17] 0.866 [22]	(Z) 0.795 [20.2] 1.031 [26.2]
HEAD TYPE CN100DA CN125DA CN160DA	(M x P/LH) M10 x 1.0 M12 x 1.5 M16 x 1.5	(N <sup>h7</sup> ) 0.472 [12] 0.551 [14] 0.709 [18]	(Q x P) M6 x 1.0 M8 x 1.25 M8 x 1.25	(R) 0.315 [8] 0.315 [8] 0.394 [10]	(S) 0.669 [17] 0.748 [19] 0.984 [25]	(T) 0.197 [5] 0.236 [6] 0.256 [6.5]	(U <sup>m5</sup> ) 0.315 [8] 0.394 [10] 0.472 [12]	(V) 1.575 [40] 1.969 [50] 2.559 [65]	(W x P) M8x125 M10x1.5 M12x1.75	(X1) 1.811 [46] 2.087 [53] 2.520 [64]	(X <sub>2</sub> ) 2.441 [62] 2.992 [76] 3.937 [100]	(Y) 0.669 [17] 0.866 [22] 1.181 [30]	(Z) 0.795 [20.2] 1.031 [26.2] 1.406 [35.7]

0.472

0.787

3.937 [100] 5.000

M16 x 2.0

5.984 [152] 1.969 [50] 2.346

# **Bill of Materials**

Generating HEADS

# **Double-Slide Head**



1 Cross-slide	9 Locknut	15 Dog Point Screw	23 Keeper Plate
2 Slide Block	10 Drive Dowel	16 Head Screw	24 Spring Washer
3 Body	11 Lock Screw	17 Spring Plunger	
4 Key	12 Caphead Screw	18 Wiper	
5 Actuator	13 Caphead Screw	19 Location Dowel	
7 Keeper Plate	14 Grease Nipple	20 Set Screw	

# **Applications**

125mm (approx. 5 in.) Single-Slide Feed-Out Head

machining three chamfers in one pass



160mm (approx. 6.25 in.) Double-Slide Feed-In Head

machining aluminum barb end fitting complete in one pass



# Applications

# 200mm (approx. 8 in.) Single-Slide Feed-Out Head

machining boot groove in brake caliper



100mm (approx. 4 in.) Double-Slide Generating Head



## 250mm (approx. 10 in.) Double-Slide Feed-In Head

performing ten operations: three faces, three grooves, and four chamfers



### 250mm (approx. 10 in.) Double-Slide Feed-Out Head

performing ten operations on an aluminum housing: three grooves, five chamfers, and two faces



160mm (approx. 6.25 in.) Double-Slide Feed-Out Head

performing six operations: three grooves, one face, one chamfer, and one I.D. turning operation



# overview

# Precision Chamfering

### Nobur® JB Series

For back-chamfering or deburring on drill presses, CNC machines, tool or turret lathes, multi-spindle machines and jig boring machines.



- Consistently accurate back-chamfering, deburring, and back-countersinking operations
- Pilots in hole for precise concentricity
- Rigid support of the cutter virtually eliminates deflection
- Micrometer-stop adjustment
- Standard pilots and cutters for hole sizes from 3/16 to 3/4" (4.75 to 19.05mm)
- Special pilots and cutters available upon request

# **Operating Principle**

Nobur<sup>®</sup> JB Series automatic back-chamfering

Illustrated below is the basic operating principle for the Nobur® JB Automatic Back-Chamfering tool.



### 1 Approach Stroke

The **Nobur**<sup>®</sup> JB tool is rotating in a machine spindle. The spindle is lowered to bring the tool into position to enter the bore.

### 2 Feed Stroke

The pilot locates in the bore, stopping against the face of the workpiece. As the spindle continues to travel, the tool is compressed so that the cutter feeds out radially into the work. The cutter is rigidly supported in the bore by the pilot to eliminate deflection and ensure concentricity.

### 3 End of Feed Stroke

Radial depth of cut is obtained when the micrometer-stop nut bottoms out. Chamfer location is controlled by rotation of the stop collar, which moves the stop collar extension up or down to position the cutter for accurate chamfer location.

# **Specifications**





IN	MM	IN	MM	STRAIGHT SHANKS
0.88	22.4	0.78	19.8	1/4 3/8 w/tang

\* Capacity means the suggested maximum chamfer diameter. Dependent upon cutting forces and bore diameter. Stated capacity is for steel.

\*\* Shank is included with head. Shanks other than shown can be supplied upon request.



1 Body Holder	5 Retaining Ring	9 Compression Spring	15 Pilot
2 Stop Nut	6 Ball Thrust Bearing	10 Ball (19/64) diameter	16 Blade
3 Stop Collar	7 Bearing Cage	11 Pilot Retaining Screw	
4 Keyed Transport Sleeve	8 Transport Assembly	12 Stop Collar Extension	

# **CNF** Precision Chamfering

Cogsdill **CNF** Series Precision Chamfering tools produce controlled chamfers on both sides of drilled or reamed holes. Designed for high production, these highly accurate tools require only one pass to generate consistent chamfers on the front and back of holes.

#### Features:

- Fast cycle times
- Available with high-speed steel or solid carbide cutters for diameters from 0.059 to 0.390 inch (1.50 to 9.90mm)
- Tools for diameters of 10mm or larger use standard replaceable ISO inserts

**CNF**1 shown here with automotive-style shank. All shank styles are available to suit the application – please specify when ordering.



# **Operating Principle**

### CNF Series PRECISION CHAMFERING

Illustrated below is the basic operating principle for the CNF Precision Chamfering tool.



### 1 Piloting

The tool diameter pilots into the hole up to the pre-formed cam opposite to the cutting edge.

### 2 Actuation

The tool travels forward and is actuated by the cam, generating the back chamfer.

### 3 Chamfering

The tool continues to travel forward, forming the top chamfer.
# **Specifications**



CNF – 1 & CNF – 2



CNF – 3

	IMETDIC1
писн	

HEAD TYPE	CAPACIT PART DIAMETER	Y RANGE MAXIMUM CHAMFER	CUTTER TOOLHOLDER DESIGN	Maximum Float	SHANKS	(A) FREE LENGTH	(B) TOOL BODY	(C) Cutter Shank	(D) REF Min Cutter Length
CNE1	0.059–0.390 [1.50–9.90]	0.030	HSS or TCT	0.059	16mm DIA	1.73	ø1.26	0.394	0.98
0.394–0.750 [10.00–19.05	0.394–0.750 [10.00–19.05]	[0.8]	ISO inserts	[1.5]		[44.0]	[ø32.0]	[10.0]	[25.0]
CNE2	0.059–0.390 [1.50–9.90]	0.080	HSS or TCT	0.118		1.85	ø1.97	0.394	0.98
CINF2	0.394–0.750 [10.00–19.05]	[2.0]	ISO inserts	[3.0]	2011111 DIA	[47.0]	[ø50.0]	[10.0]	[25.0]
CNF3	0.750–1.250 [19.05–31.75]	0.080 [2.0]	ISO inserts	0.118 [3.0]	20mm DIA	1.85 [47.0]	ø1.97 [ø50.0]	0.630 [16.0]	0.98 [25.0]

### **Bill of Materials**

### **CNF**1



1 Front Bush	6 Spacer	11 Ball	16 Cage
2 Set Screw	7 Inner Body	12 Guide Bush	17 Dowel
3 Lock Nut	8 Ball	13 Dowel	18 Thrust Washer
4 Shank	9A Cage	14 Ball	19 Dowel
5 Set Screw	10 Selloc Pin	15 Spring	

### **Bill of Materials**

#### CNF Series PRECISION CHAMFERING

### **CNF**2







1 Front Bush	7 Inner Body	12 Guide Bush	18 Thrust Washer
2 Set Screw	8 Ball	13 Dowel	19 Dowel
3 Lock Nut	9A Cage	14 Ball	
4 Shank	10 Selloc Pin	15 Spring	
5 Set Screw	11 Thrust Brg	17 Dowel	

### **Bill of Materials**

### **CNF**3



SECTION VIEW



1 Front Bush	7 Inner Body	12 Guide Bush	18 Thrust Washer
2 Set Screw	8 Ball	13 Dowel	19 Dowel
3 Lock Nut	9A Cage	14 Ball	
4 Shank	10 Selloc Pin	15 Spring	
5 Set Screw	11 Thrust Bearing	17 Dowel	

#### Nobur® JB Tool

back-chamfers both sides of holes in large single-speed gear ring



Nobur® JB Tool

deburrs back side of yoke



### CNF1 Tool

machining front and back chamfer on automotive component











STAGE 3

### Nobur<sup>®</sup> JB & CNF Series

PRECISION CHAMFERING

#### CNF3 Tool

performing front and back-chamfering operation using tool with modular holder







**Nobur<sup>®</sup> JB & CNF** Series PRECISION CHAMFERING

### **CNF**1 Tool

machining back chamfer on differential housing





#### **CNF**1 Tool

machining back-chamfer with undercut



### **CNF**1 Tool

boring groove with chamfer on each end of small bore





# **Application Data Sheet**

To ensure that the correct tool is furnished for your particular

Recessing

**GENERATING HEADS &** PRECISION CHAMFERING

plication, please photocopy, complete this data sheet, and close it with your order or request for quotation. This is a quirement for ALL recessing applications, including internal d external facing, chamfering, and back-spot facing, as well grooving.		Det	-		
		Date	Date		
		Quot	ite No.		
nation					
	State	Zip			
	Fax				
utor					
cifications					
/tvpe					
<u></u>					
aded for retention knob or drawba	ar. specify thread si	ize			
er (B) 4	Groove width (W)				
dimension (L)					
(A) / Groove depth (D)					
n required in groove?	If yes, specify				
	Type and conditio	on			
estrictions? Length	Diameter	Rot	ating	_	
ight limit, please specify	Used in a tool cha	anger? Yes	No		
Horizontal	Vertical	Star	tionary		
ol to be used with a fixture? Yes	No				
ut drawings must be attached or s	sketched				
be held or clamped?					
ed will be used? Hand	Power				
t feed: External	Internal through s	pindle			
	Internal with rotati	ing collar			
applies, please specify					
	iccopy, complete this data sheet, an er or request for quotation. This is a essing applications, including intern infering, and back-spot facing, as we hation    infering, and back-spot facing, as we hation    intor    intor	icocopy, complete this data sheet, and er or request for quotation. This is a essing applications, including internal imfering, and back-spot facing, as well    nation	iocopy, complete this data sheet, and ar or request for quotation. This is a ressing applications, including internal imfering, and back-spot facing, as well  Data    nation  Quo    state  Zip	occpy, complete this data sheet, and error request for quotation. This is a essing applications, including internal infering, and back-spot facing, as well  Date    nation  Quote No.    state  Zip	

(continued on next page)

### **Application Data Sheet**



GENERATING HEADS & PRECISION CHAMFERING

(continued)

**Additional Comments** 

#### IMPORTANT

PART PRINT OR DETAILED SKETCH MUST BE SUPPLIED

Please indicate location of grooves or recesses, dimensions, tolerances, and direction of tool approach. In multiple groove applications, supply (L), (W) and (B) dimensions for each groove.



